



## Cleaning Your NIS Dyneema Sling

### What To Use

### How To Clean

1. Submerge Sling into 55 gallon drum for 8-10 hours
2. Pull out sling and let cleaner drain into tub
3. When rinsing do not directly power wash your Dyneema sling
4. Water used shall be kept under 150 degrees
5. After Rinse Hang Dry
6. Repeat in time as necessary

The Product  
Consume Micro-Muscle  
Has Been Generally  
Approved By The  
Manufacturer And Is  
Available In Up To  
55 Gallon Drums

A Non-Solvent  
Surfactant Or  
'Green' Product  
Cleaner Shall Be Used.  
(See Website Below)

